

#### DECKBLATT ZUM ORIGINAL-DATENBLATT DES HERSTELLERS

# 1500W | DATENBLATT GERÄTE

**HERSTELLER** Camtec Power Supply GmbH **PRODUKTSERIE** CPS-i1500-Serie [U+I regelbar]

Ihr direkter Ansprechpartner für Camtec-Produkte!

Die Ing. Erhard Fischer GmbH ist Ihr zuverlässiger Partner für die Produkte von Camtec Power Supply. Wir bieten Ihnen nicht nur hochwertigen technischen Support, sondern auch kompetente Beratung und maßgeschneiderte Lösungen für Ihre individuellen Anforderungen.

Ob Standardprodukt, kundenspezifische Geräte oder <u>Schaltschrankbau</u>. Wir freuen uns, Sie bei Ihrer Lösungsfindung mit eingehender Kundenberatung kompetent unterstützen zu können.

Kontaktieren Sie uns für technische Beratung oder ein individuelles Angebot!

Wir freuen uns auf das Gespräch mit Ihnen.



+43 2236 42694-40

powersupply@ing-fischer.at

Ing. Erhard Fischer GmbH

Weissenbach 101 | AT-2371 Hinterbrühl

www.ing-fischer.at



ING. ERHARD FISCHER GMBH

Immer die passende Lösung für Industrie-Stromversorgungen, Heizfolien & Messtechnik





# **CPS-i1500**

# 1500W Laboratory Power Supply DIN-Rail



### Features:

- Real time C/V programming
- Real time & value C/V-monitoring
- Reference voltage f. autonomous programming
- Inhibit for safe interlocking
- Remote Shutdown
- Sense control 2V per load line
- Power Good Relay DC-ok
- · Quick down programming option PS

- Precise dynamics on load change
- Series & parallel operation N+1
- Stepless fan-controlled heat dissipation
- Electronic Inrush Limiter 14,7Arms
- High reliability, shock & vibration proof
- Efficiency up to 94%
- EMI/EMS EN61000-6-2,3, EN55032 class B
- EN61010-1, EN61010-2-201, EN62368-1

Model	Voltage programmable	Current programmable
CPS-i1500.018	0 – 18Vdc	0 – 75,0A
CPS-i1500.030	0 – 30Vdc	0 – 62,0A
CPS-i1500.060	0 – 60Vdc	0 – 31,0A
CPS-i1500.090	0 – 90Vdc	0 – 21,0A
CPS-i1500.150	0 – 150Vdc	0 – 12,5A
CPS-i1500.300	0 – 300Vdc	0 – 6,3A
CPS-i1500.400	0 – 400Vdc	0 – 4,7A











#### Technical description - a unique mechanical concept

The Camtec CPS-i models are high-precision lab power supplies "Made in Germany". These power supplies are designed for power systems in the testing automation.

For more than 25 years the Camtec Power Supplies manufactures high-end switch mode power supplies in Germany. A field breakdown of below 0,004% over a 10-year period under review approves our ambitious quality concept. Each manufactured Camtec product passes several 100% tests for each detailed function and a full-load Burn-In test.

Although it is not required from the safety norms our production applies a routine safety test to each manufactured device, even if it is an extra low-voltage model. The components in the assembled device pass stress aging to achieve an even level and to prevent from delayed failures. Our internal product engineering guidelines provide a clear target: Camtec product reputation must say "mount and forget". Quality is never a mere promise for our team.

The CPS-i1500 laboratory power supplies provide low noise and ripple, a very quick programming, and a precise setting at high load changes. With an efficiency up to 94% the devices are highly energy efficient.

Equipped with high-end capacitors of outstanding lifetime our power supplies guarantee a very long and reliable operation time. The circuit design of the CPS-i Series allows cope playing with complex loads. The internal protection circuits protect the power supply and the connected system, even in exceptional situations. The CPS-i series is protected from high transients by strong filters with high energy efficiency. All inputs and outputs and the interface are electrically isolated. The design specifications call for the highest standards of safety and interference suppression. The unit is designed in accordance with the EN60950-1, EN62368-1, EN61010-1, EN61010-2-201 and the EMC-compatibility with EN55032.

The forced air-cooling system with load-dependent variable fan control, allows a detached position in the system. In selecting the fan, as with all our power supplies, in our opinion we use with the German manufacturer EBM Papst the highest quality and most reliable devices in the world market.

The special streight though controlled heat emission design supports easy baseplate cooling with the help of an optional wall mount plate.





#### **Features**

#### **Idling behavior**

The CPS-i Series is permanently open-circuit proof. When an output voltage is preset it comes stable. If a load is switched suddenly, the unit stabilized within <1ms. An overshoot of the output voltage is irrelevant.

#### Start behavior

The power supply has a start delay of 400ms to stabilize all measuring circuits for the interface messages accurately. The power supply starts with a ramp (soft start) of 100ms. The output voltage does not overshoot - regardless of whether a load is connected or not.

#### Galvanic isolation and insulation

The switching power supply is galvanically isolated between the input and the output. All major inputs and outputs of the interface are electrically isolated from the DC power outputs and sensing. The sensing, Ureg, Ireg, Umon, Imon and Iref are connected to the DC power output.

#### Voltage programming (Ureg)

The output voltage of the CPS-i power supply can be adjusted by a control signal. The setting is linear to the input signal. The power supply operates data stable even at very low output voltages.

#### **Current programming (Ireg)**

The output current of the CPS-i power supply can be adjusted by a control signal. The setting is linear to the input signal. The power supply operates data stable even at very low output currents.

#### **Voltage Monitor (Umon)**

The power supply provides real-time monitoring of the output voltage. It is the exact and real value at the output terminals. If the sense line is used, the real value is measured directly at the load. The latency signal preset to the measured value is negligible since the control circuit is constructed completely analogously.

#### **Current Monitor (Imon)**

The power supply provides real-time monitoring of the output current. It is the exact and real value at the output terminals. The latency signal preset to the measured value is negligible since the control circuit is constructed completely analogously.

#### Constant Voltage or Constant Current Mode (CV/CC)

The device can optionally be operated as a DC voltage source or a constant current source. The operating mode is signaled via LED.

#### Reference Voltage (Uref)

The devices feature an auxiliary reference voltage to operate external potentiometers. The Uref voltage can be set to 5,2V or 10,4V 5mA via the DIP-switch.

#### Sense Mode

The power supply has a sense mode to compensate for voltage drops of 2V per load line.

#### Inhibit Mode (Interlock)

The inhibit circuit reliably prevents unintentional starting of the power supply. The control loop is internally locked. Since this blocking is done progressively it is active even when the control signal, is missing due to a cable break or temporarily suspends. A premature restart of the power supply is prevented.

The inhibit input can be connected to a relay or switch. If the contact is interrupted, the power supply is switched off. If the contact is closed again, the power supply restarts.

#### Remote Shutdown (SD)

All the models are featured with an external shutdown (switch/open collector)

#### **Digitale Interface**

The standard equipment of the power supply is an analog interface.

Optionally, the unit can be equipped upon request with a digital USB 2.0 interface. Options include a software and a DOM interface for easy control over standard software like LabView or others.

#### **DC Power Good Relay**

The power good relay connection indicates over device temperature and low AC supply voltage.

#### **Over Temperature Thermal Shutdown (OT)**

The device has a thermal monitoring: shutdown with automatic restart.

#### Fast Down Programming & PowerSink (PS)

For fast down programming an internal PowerSink is offered as an option. The current sink discharges the output electrolytic capacitors and eleminates back feed energy. A further output allows to control external PowerSink modules. The internal current sink for quick programming must be installed at the factory.

#### ST-HD (ST Heat Dissipation)

Our aligned and controlled heat dissipation design opens possibilities that are formerly being reserved to custom design power supplies: Hard mount of the CPS-i1500 power supply modules on a wall allows easy access to base plate cooling.

In practice that means that one can mount the modules onto a thermal conducting wall to unsure that a sigificat part of the losses wil be transported directly out of the power supply unit.





Technical Data Table										
AC Input Range	184-264Vac									
AC Input Frequency	47-63Hz	47-63Hz								
DC Input Range	250-375Vdc	250-375Vdc								
AC Input Rated	230Vac <13	230Vac <13,5A								
DC Input Rated	250Vdc <7,5	A 375Vdc <5	5,0A							
DC Voltage programmable	0 - 18Vdc									
DC Current programmable	0 - 75A									
Over Voltage Protection	22Vdc	35Vdc	70Vdc	105Vdc	175Vdc	350Vdc	450Vdc			
Ripple Noise 230Vac 20MHz	40mVpp	80mVpp	120mVpp	150mVpp	200mVpp	300mVpp	400mVpp			
Power Rated	1500W, 184	-264Vac								
Cooling	Continuous	ly controlled	fans from EBM	Papst (Germa	any)					
Efficiency	Up to 94% 2	30Vac at full	load	•	•					
Short Circuit Resistance	yes									
Open Circuit Protected	yes									
Base Load (OCP)	Non require	d (open circu	it protected)							
Load Regulation	< ± 0.05% 0	·100%	· ·							
Load Regulation Time		ad switch 10-1	100%							
Rise Time and Latency	0V - Vout <sub>ma</sub>	x, 15ms over a	all							
Accuracy				0.5%. lmon: ≤ :	± 1%, Uref: ≤ ±1	1%				
Temperature Control	· ·	, ,	•		e measuring p		(0mm)			
Hold Up Time			fering at full lo		<b>3</b> p		- ,			
Inrush Current					protection (no	simple NTC)				
MCB (Circuit Breaker)	16A curve E	, .			production (inc	,				
Startup Delay	Typ. 400ms									
Softstart	Typ. 100ms									
Ambient Temperature	71		derating 2,5%	°C >60°C						
Storage Temperature	- 40°C+85									
Ambient Conditions		_	ensing @ 25°C.	climate class	3K3, pollution	degree 2				
ROHS		(EU)2015/863	J - /		one, ponemon	40g.00 =				
REACH	EG No. 1907									
EMI			s B, radiated cl	ass A. FN6100	00-6-3					
EMS	EN61000-6-		o b, radiatou o							
Safety		='	01. FN62368-1	not 400Vdc m	odel), EN60950	-1. FN60204-1				
Protection Class I		ion required	, 2.102000 . ,	(1101 1001 40 111	000.,, =1100000	, ,				
Isolation Input to Output	3000Vac	.o.i roquirou								
Isolation Input to Case	2500Vac									
Isolation Output to Case		0Vdc= 2800V	10							
MTBF (IEC61709)	, -			tatistic time h	etween failures	after renairs)				
MTTF (IEC61709)			ailure: statistic			and repairs,				
Dimensions (HxWxD)	161x250x12		and of old is the	timo to cver it						
Weight	4,1kg / 9,0lb									
AC Terminals	, , ,		AWG22 – AWG	6 / 0 5 — 16mm	n² (I N PF)					
DC Terminals			x AWG22 – AWG	,	. , , ,					
DC Tellilliais	Output Scre	w i cillillal 4	A AVIGEZ - AVI	140 / 0,5 - 10II	IIII <sup>-</sup> (+ +/ <i>)</i>					

Programming Time Vout [ms]								
Model	0-18Vdc	0-30Vdc	0-60Vdc	0-90Vdc	0-150Vdc	0-300Vdc	0-400Vdc	
Rise Time 0-100%, 10/100% load, [ms] typ.	15/15	15/15	15/15	15/15	15/15	15/15	15/15	
Slew Rate 90-10%, 10/100% load, [ms] typ.	30/3	60/6	44/4,4	32/3,2	42/4,2	38/3,8	68/6,8	
Slew Rate PS-Option 100-0%, 0% load, [ms] typ.	150	150	150	150	150	150	150	
Output Capacity, [mF] typ.	15,76	15,76	2,84	0,94	0,44	0,10	0,10	





# **Manual and Technical Details**

Anal	Analog Interface CON1 (Connector Model Weidmueller 1277310000 = included)								
Pin	Name	Type	Function	Signal	Remarks				
1	Ureg +	Input	Voltage Programming	Select 0-5V, 0-10V,	1 MΩ working resistance with Vprog				
2	Ureg -	Input		0-20mA, 4-20mA	500 $\Omega$ working resistance with Iprog				
3	Ireg +	Input	Current Programming	Select 0-5V, 0-10V,	1 MΩ working resistance with Vprog				
4	Ireg -	Input		0-20mA, 4-20mA	500 $\Omega$ working resistance with Iprog				
5	Umon +	Output	Voltage Monitor	Select 0-5Vdc/5mA,					
6	Umon -	Output		0-10Vdc/5mA					
7	lmon +	Output	Current Monitor	Select 0-5Vdc/5mA,					
8	lmon -	Output		0-10Vdc/5mA					
9	Uref +	Output	Reference Voltage	Select 5,2Vdc or 10,4Vdc					
10	Uref -	Output		5mA					

Anal	Analog Interface CON2 (Connector Model Weidmueller 1277280000 = included)									
Pin	Name	Type	Function	unction Signal Remarks						
1	DC-OK +	Input	Closers, Signal DC OK	Relay	Potential-free break contact					
2	DC-OK -	Input								
3	SD +	Input	Control Signal Shutdown	Switch / Open Collector						
4	SD -	Input								
5	INH +	Output	Control Signal Inhibit	Switch						
6	INH -	Output								

Anal	Analog Interface CON3 (Connector Model Weidmueller 1597380000 = included)								
Pin	Name	Type	Function	Signal	Remarks				
1	AUX +	Input			Potential-free				
2	Sense +	Input							
3	Sense -	Input							
4	AUX -	Input							


Analo	Analog Interface CON4 (Connector Model Weidmueller 1597360000 = not included)							
PS +	PS +	Output	External Power-Sink	Trigger	This connection is without function			
PS -	PS -	Output			for the standard CPS-i1500			


Config	Configuration of the Analog Interface via Dip-Switch										
Mode	<b>S1</b>	S2	S3	S4	<b>S5</b>	<b>S6</b>	<b>S7</b>	<b>S8</b>	<b>S9</b>	S10	
0-5V	0	0	0	0	0	1	0	0	0	0	
0-10V	0	1	0	0	1	0	0	1	1	1	
0-20mA	1	1	0	1	1	0	0	1	1	1	
4-20mA	1	0	1	1	0	0	1	1	1	1	

LED Signal Indication									
LED	Over Temp.	Inhibit Open	Shut Down	Constant [V]	Constant [C]				
CV	OFF	OFF	OFF	ON	OFF				
CC	OFF	OFF	OFF	OFF	ON				
ОТ	ON	OFF	OFF	OFF	OFF				
SD/INH	OFF	ON	ON	OFF	OFF				













#### Programming/Monitoring V/C Analog Interface (Ureg /Ireg) (Umon/Imon)

The standard programming of the CPS-i Series is an analog interface. The output voltage is linearly proportional to the adjusted analog control signal. If the control signal 0V and/or 0A applies the power supply delivers 0V at the output. The power supply is already working from 0V output voltage and low load with high precision.

The monitor signal is analog linear to the output voltage. The monitor signal for current and voltage is the real value that is measured directly at the output of the power supply. If a sense line is connected to compensate for the voltage drop across the load lines, the monitor signal is exactly the value that is measured at the connection point of the sense line. The description of the power supply in the sense operation is carried out in a separate section.

The analog inputs and outputs are non-floating. The mass is connected to the DC negative output.

The adapter provides the ability to select the desired input / output via a DIP switch. The burden of the control voltages is  $1M\Omega$ . The burden of the current interface is  $500\Omega$ . The latency to full compensation of V/C on the interface from 0-100% is 15ms for all CPS-i models.

If the power supply is operated with a low load, the down-programming time up to the desired set point may be very long. The power supply has large built-in capacitors and an enormous energy reserve. A similar effect occurs by skidding input energy, which is not easily removed from the power supply. A PowerSink (PS) modul can be ordered as an option for each CPS-i power supply unit. The PS option is used for fast down programming and the degradation of skidding energy fed. The option must be equipped in the factory.


For further information about the PS option, please refer to the technical details in a section PS-option.

#### Compensation of Load Line Drop Voltage (Sense +/-), standard operation mode


The CPS-i power supply has a Sense Mode to compensate for the voltage drop over long load lines. The compensation amounts to a maximum of 2V per load line. Under certain circumstances, it can be expected to apply more complicated external interference suppression. If sense is not used, Sense + and Sense - shall necessarily be connected by short bridges to AUX + and AUX - (factory setup). Make sure that +/- connections are matching! **WARNING!** Reverse polarity of the sense lines can cause damages to the power supply unit.

Sense operation: Remove the bridges between Sense +, Sense -. Connect the sense lines directly to the load. Pay attention to the polarity of plus and minus of the load to prevent damage to the power supply. To avoid interference, twist the sense lines. To reduce inductive effects, we recommend that the load lines position is close to each other. To supply a pulsating load, the use of an electrolytic capacitor and a cermic capacitor has proved. The internal Over Voltage Protection (OVP) of the power supply controls the DC power directly to the DC output terminals. In case of an error the OVP acts automatically (see OVP values corresponding table).

The sense terminals are directly connected to the power outputs.



Lokal Sensing (factory setup)



Remote Sensing (twisted sense lines)







#### Compensation of Load Line Drop Voltage (Sense ++/--) battery charger operation mode

#### Remote Sensing as a battery charger

If the CPS-i power supply unit is used as a battery charger, it is recommended to refrain from sensing. It can lead to severe damage to the power supply, if the polarity of the sense line is confused (field experience: such error often occurs when system service is required, e.g. when the batteries are changed). If it is necessary to use sensing, proceed as described in the figure below. Proven approaches are 250mA for the fuses and 3...5A load capacity of diodes.

WARNING! Reverse polarity of the sense lines can cause damages to the power supply unit.





#### **External Shutdown (SD)**

The power supply is set to the Shutdown mode, when the control input is either shorted via a relay contact, a switch contact or an NPN transistor with open collector (voltage drop <1V, current typ. 1,5mA).

If the shutdown repeals the power supply starts again.

Using the soft-start, the current and the voltage rises within continuously to the default set values. Between control input SD, power input and power output is a reinforced isolation of max. 400Vdc and a basic isolation of max. 600Vdc working voltage.



#### Inhibit / Interlock (INH)

The power supply is equipped with a control input Inhibit (INH) to interlock a DC-shutdown of the power supply.

For the nominal operation of the power supply the connections of the control input "INH" must always be short-circuited. The power output is switched off as soon as the connection between the contacts of the control input INH is interrupted. If Inhibit is repealed, the power supply starts again. Using the soft-start, the current and the voltage rises continuously to the default set values. Between control input INH, power input and power output is a reinforced Isolation of max. 400Vdc. Between the INH contacts applies a current of typical 2mA.



WARNING! It is prohibited to apply an external voltage to the inhibit connection! The CPS-i unit can be seriously damaged! Never connect a resistor to the INH interface. The Control input INH can only be connected to a floating contact like a switch or a relay. Between control input INH, power input and power output is a reinforced Isolation of max. 400Vdc and a basic isolation of max. 600Vdc working voltage.





#### **Power-OK Relay (DC Power Good)**

The alarm signal DC OK has potential-free relay contacts. The contacts are closed (relay coil is energized) when the power output is active. In (SD) shutdown or in (INH) inhibit mode, the contacts are closed. The contacts are open when the power output is inhibited by OT or low AC supply voltage at the AC inputs. Contact load (resistive load): 30Vdc/1A, 60Vdc/0.3A, 30Vac/0.5A. Betwenn the intermediate relay contact, power input and the power output is a reinforced Isolation max. 400Vdc and a basic isolation of max. 600Vdc working voltage.

#### Over Voltage Protection (OVP)

If an over-voltage occurs to the output (for example, defective components, external feed voltage), it is followed by the shutdown of the power output. A periodic restart attempts (ticker operation period 400ms).


#### **Over Temperature Shutdown (OT)**

The alarm LED OT lits when the temperature of the power supply is higher than the over-temperature protection threshold.

#### **C/V Chart and Operating Point**

The output voltage set Vout is always linear proportional to the control signal Ureg.

The desired control signal is selected via the DIP switcher: 0-5V, 0-10V, 0-20mA oder 4-20mA.





Model	Value UA1 (V)	Value IA1 (A)	Value UA2 (V)	Value IA2 (A)	Pmax (IA1/IA2)
CPS-i1500.018	18Vdc	75,0A	18Vdc	75,0A	1350/1350W
CPS-i1500.030	30Vdc	50,0A	24Vdc	62,0A	1500/1488W
CPS-i1500.060	60Vdc	25,0A	48Vdc	31,0A	1500/1488W
CPS-i1500.090	90Vdc	16,7A	72Vdc	21,0A	1503/1512W
CPS-i1500.150	150Vdc	10,0A	120Vdc	12,5A	1500/1500W
CPS-i1500.300	300Vdc	5,0A	240Vdc	6,3A	1500/1512W
CPS-i1500.400	400Vdc	3,7A	320Vdc	4,7A	1480/1504W

#### **Inrush Current Protection (electronic)**

The power supply unit has an electronic current limiter (230Vac=14,7A<sub>rms</sub>/20,7A<sub>peak</sub>).

It is a precisely working circuit instead of a usual simple NTC solution. The accuracy is ±10%, regardless of the operating temperature and the duty cycles (interval ≥10s). We recommend the smallest circuit breaker a characteristic B with 16A.










#### **Temperature Derating**

The maximum ambient temperature during operation is + 70°C. If the overtemperature protection is activated, the power supply but not the fan is switched off.

The measuring point is 50mm outside the power supply. The power supply unit starts automatically when it has cooled down.




#### **Series Operation**

Two or more units of the same model and output voltage can be operated up to a total voltage of 600Vdc in series (not applicable with EN62368-1). The CPS-i1500 models are to be operated with floating output when connected in series. Such the output terminals must not be connected to earth (GND/PE). Due to the dielectric strength of the internal components used, only the models with an output voltage of 90Vdc and later are approved for series operation. Other power supplies are not approved for series operation above 60Vdc. If the units are remotely controlled via the analog interface it is compulsory to use a potential-free control voltage!

#### Parallel Operation & N+1 Decoupling

To increase the overall power of the power supply, two or more devices of the same model with the same output voltage may be operated in parallel. We recommend using a busbar for the DC power connector. Make sure that the cable lengths and cable cross-sections of all power supplies to the busbar or to the star point are identical. If you want to use the sensing function, connect it also to the star point or busbar. To avoid measurement errors, select the line length from the neutral point or from the busbar to the load as short as possible and use the maximum possible conductor cross-section.

The CPS-i models have no internal O-ring diode, to operate the devices redundant N+1.




#### Electrical Safety (Factory-Test / Field-Test Owner)

	T	Α	В	C1)	D	E
Type Test	60s	2500Vac	3000Vac	500Vdc	3000Vac	500Vdc
Factory Test	5s	2000Vac	2000Vac	500Vdc	900Vdc	500Vdc
Field Test	2s	2000Vac	2000Vac	500Vdc	900Vdc	500Vdc
Cut-off current	setting	>25mA	>25mA	>1mA	>1mA	>1mA

¹) ≥60Vdc= 2800Vdc

Type and factory test are the manufacturer. While repeating damage can happen to the power supply unit. For the field test (owner) follow the below instruction:

- a) Use suitable test equipment, raising the voltage slowly.
- b) Short circuit L1 and N, and all the DC output terminals.
- Use only test voltages of 50/60Hz. The outputs are unearthed and therefore they have no resistance to GND/PE.
- d) If the residual voltage is ≥60Vdc, observe the safety standards.
   Use only specially insulated screwdriver to trim the Ua/Ia.







# **Available Options**

#### **PS Option for Quick Downward Programming (PSOPT)**


#### **Quick Down Programming:**


The input capacitance of a power supply can be discharged only slowly at low load. A quick downward programming of the output voltage of an almost non-loaded power supply is not possible. This fact leads to undesirably long cycle times on a test bench. The PS option works as an electronic circuit. It communicates with the control circuit of the power supply and therefore permits a much higher dynamics of the system, as an external passive base load.

#### **Back-Feed Energy:**

In the back-feed power by a consumer a regenerative current is charging the output capacitors. The output voltage will increase. The following formula shows dv/dt=i/C.

When an electronic current sink is used, the output voltage remains constant at the set value. The current sink provides a quick dynamic response.








Fig 1 Fig 2 Fig 3

A Power Sink (see Fig. 1) enables fast down programming at low load conditions or without a load. For comparison, see Figure 2 (without) and Figure 3 (with PS option).

The PS-option must be installed in the plant because it is not accessible from the outside. It is necessary to match the power supply after installation and perform electrical safety testing. We therefore recommend a required a necessary PowerSink option to be purchased with the power supply unit.

#### **Retrofit PS option:**

Individual trained CPS-i dealer are pre-retrofit able. Alternatively, a CPS-i power supply may also be sent to the factory. Please apply for this an RMA number from our service.

#### **Test Certificate and Calibration**

Optionally we offer with the delivery of a CPS-i power supply a Manufacturer's Inspection Certificate of electrical setpoint / actual values. The power supply then is "calibrated". Such Manufacturers Calibration Certificate for each power supply can uniquely be assigned via the device serial number.

A manufacturer calibration of a CPS-i can frequently be done via controlled recirculation on a regular basis. Please request the help of your local CPS-i dealer or contact us directly: service@camtec-gmbh.com







# **Mechanics**

#### ST-HD Baseplate Cooling & Temperature Management

The temperature management of the CPS-i1500 series provides a direct dissipation of the main energy losses. The internal coolers of the output diodes and the power FETs connect to the back-plate cooler. It is possible to dissipate about 40 - 50% of the energy losses out of a system while using the Baseplate cooling bundle 2201002001 to hard mount the unit to a plane and heat conductive surface.





Mounting Instruction: recommended airflow space below and above is 50mm (2 Inch)






#### Mechanics & Installation Instruction of the CPS-i1500


Stable metal/aluminium housing IP20. To allow adequate convection, a free air space of 50mm (top/bottom) and 10mm (sidewalls) is required; and for active devices 15mm space from the sidewalls. For proper air convection it is necessary to install the CPS-i1500. One can use the DIN-Rail installation (equiped standard) with our patented 35mm DIN-Rail bracket according to EN60275. It is easy to mount/dismount while snaping it onto the 35mm DIN-Rail - no tools necessary. A wallmount back plate (option) is available, too.

It is not allowed to install the CPS-i1500 in other mounting direction then as shown in the drawings.



#### **Back Plate Option / DIN-Rail Standard**

(The CPS-EC1500 is always delivered for DIN-rail mount, the back-plate is an optional part that shall be mounted from the customer. The threads from the DIN-rail mounting brackets shall be used. All screws are included into the Back-Plate Kit.)







Connections								
Clamping Yoke Connector Specifications								
	•	Input / Output connection	ons	Signal conr	nections plugs			
Tightening torque min	max.	1,2 - 2,2Nm (blade 1,0x5	,5 DIN5264)	$0,2-0,25N_1$	m (blade 0,4x2,2 DIN5264)			
Touch-safe protection ac	c. to DIN VDE 0470	IP20 plugged/ IP10 unplu	gged	Not applicab	ole			
Clamping range, min n	nax.	0,5 - 16mm <sup>2</sup> / AWG26 - A	AWG6	0,2 – 1,5mm	1 <sup>2</sup> / AWG28 – AWG14			
Solid, H05(07) V-U min	max.	0,5 – 16mm <sup>2</sup>		0,2 – 1,5mm	J <sup>2</sup>			
Stranded, H05(07) V-U mi	in. – max.	6 – 16mm²		0,2 – 1,5mm	1 <sup>2</sup>			
Flexible, H05(07) V-U min	. – max.	0,5 - 16mm <sup>2</sup>		0,2 – 1,5mm	1 <sup>2</sup>			
w. plastic collar ferrule, [	OIN 46228 pt 4 min. – max.	2,5 – 10mm <sup>2</sup>		0,2 – 1,5mm	1 <sup>2</sup>			
w. wire end ferrule, DIN 4	6228 pt 1, min. – max.	2,5 – 10mm <sup>2</sup>		0,2 - 1,5mm <sup>2</sup>				
Plug gauge in accordance	e with EN 60999 a x b; ø	5,4 x 5,1mm; 5,3mm		2,4 x 1,5mm	ı; 2,3mm			
Pitch (P)		10,16mm		3,5mm				
Wire Stripping Leng	th (fine wired)							
Nominal Cross Section	Wire End Ferrule	Stripping Length	Wire End Fer	rule	Stripping Length			
0,25mm <sup>2</sup>	H0,25/5	5mm	H0,25/10 HBI	-	8mm			
0,5mm <sup>2</sup>	H0,5/6	6mm	H0,5/12 OR		8mm			
1,0mm <sup>2</sup>	H1,0/6	6mm	H1,0/12 GE		8mm			
2,5mm <sup>2</sup>	H2,5/12	12mm	H2,5/19D BL		14mm			
4,0mm <sup>2</sup>	4,0mm <sup>2</sup> H4,0/12		H4,0/20 GDR		14mm			
6,0mm <sup>2</sup> H6,0/20		12mm	H6,0/20 SW		14mm			
10,0mm <sup>2</sup>	H10,0/12	12mm H10,0/22 EB		15mm				
The length of ferrules is to the pitch (P)	be chosen depending on the	rated voltage. The outside of	diameter of the	plastic collar s	should not be larger than			

Ordering Information Ordering Codes		
CPS-i1500.018(R2)	0-18Vdc	3041112001CA
CPS-i1500.030(R2)	0-30Vdc	3041112002CA
CPS-i1500.060(R2)	0-60Vdc	3041112004CA
CPS-i1500.090(R2)	0-90Vdc	3041112005CA
CPS-i1500.150(R2)	0-150Vdc	3041112006CA
CPS-i1500.300(R2)	0-300Vdc	3041112007CA
CPS-i1500.400(R2)	0-400Vdc	3041112008CA
CPS-i1500.018PS(R2)	PowerSink / Quick Downward Programming	3041112011CA
CPS-i1500.030PS(R2)	PowerSink / Quick Downward Programming	3041112012CA
CPS-i1500.060PS(R2)	PowerSink / Quick Downward Programming	3041112014CA
CPS-i1500.090PS(R2)	PowerSink / Quick Downward Programming	3041112015CA
CPS-i1500.150PS(R2)	PowerSink / Quick Downward Programming	3041112016CA
CPS-i1500.300PS(R2)	PowerSink / Quick Downward Programming	3041112017CA
CPS-i1500.400PS(R2)	PowerSink / Quick Downward Programming	3041112018CA
Certificate Calibration	Separate works certificate for manufacturer calibration of the power supply	-
Back Plate Kit	Hart mount plate kit including screws	2201002001CA





Safety regulations: Please read these instructions completely before using the equipment. Keep these instructions on to hand. The device may only be operated by trained specialist staff.

#### Installation:

- 1) The device is designed for devices and systems that meet the standard requirements for hazardous voltages, power, and fire prevention.
- 2.) Installation and service only by trained persons. The AC power must be switched off. The work is to be labelled; accidental reconnection of the system must be prevented.
- 3.) Opening the device, its modification, loosening bolts, or operation outside the specified herein specification or in an unsuitable environment, has the immediate loss of warranty to follow. We disclaim any responsibility for any resulting damage to persons or things.
- 4.) Note: The device must not be operated without an upstream circuit breaker (CB). We recommend the use of B-Type 16A. It is prohibited to use the unit without PE. It may be necessary upstream device has a power switch.

#### Warning:

Non-compliance these warnings can result in fire and serious injury or death.

- 1. Never operate device without PE connection.
- 2. Before connecting the device to the AC network, make wires free of voltage and assure accidentally switch on.
- 3. Allow neat and professional cabling.
- 4. Never open nor try to repair the unit. Inside are dangerous voltages that can cause electrical shock hazard.
- 5. Avoid metal pieces or other conductive material to fall into the item
- 6. Do not operate the device in damp or wet conditions
- 7. Do not operate the unit under EX-conditions



All parameters after 15 minutes of continuous operation at full load / 25°C / 230Vac 50/60Hz, unless otherwise indicated.